



Electric Vent

Your van has been fitted with our new electric vent. The purpose of this is to suck steam out when your bathing the dog and bring in fresh air whilst your grooming. The vents are directional so you can point them to blow air onto you whilst you work.



When your bathing the dog, press the switch to extract to suck the steamy air out, when you have finished, press the switch to off and then press down to intake to bring fresh air in. You must turn the fan off in-between functions and wait for the fan to stop (dont press extract straight to intake) to allow the motor time to change direction otherwise you can blow a fuse or damage the motor and possibly void the warranty.

